

MIXING Air Krete INSTRUCTIONS:

Cement SIDE ... 1/2 FIELD READY Drum of Cement

1 Bag Mix

1 Start With a CLEAN Drum of 150lbs Clean COLD Water



2 Slowly Add
1 Large Ziplock Cement
Additive Baggie
(1/4 Airkrete Unit)
Mix High RPM

Then dip your
strainer to check
for lumps. If clear
go to next step.
If not strain out lumps



3 Slowly Add 1 Talc 50lb Bag 50lbs
Mix High RPM 2 to 3 min

Then dip your strainer to check for lumps. If clear
go to next step. If not strain out lumps



4 Slowly Add
1 Mgo 55lb Bag Mix
High RPM
1.5 Min

Then dip your
trainier to check
for lumps. If it is not clear mix 1
more Min. if clear of lumps set
the mixer on low and pump.
If not clear remove clumps set
mixer on low and pump.

Check your date on the Mgo

Once this is mixed it is a HOT
DRUM and must be installed
imediatly until you are ready
the rinse the pumps.

1bag mix = 1/4 Airkrete Unit.....
1/2 FIELD READY
DRUM of CEMENT